

you can **RELY** on

CEMENTAID

The Way to Better Concrete

FOR WET AREA

WELDCRETE CRACK FILLER

FUNCTION & BENEFIT:

A waterproof, crack resisting, non-shrink and durable crack filler for wet areas. **WELDCRETE CRACK FILLER** has a good adhesion, a corrosion resistant to chemicals and suitable for repairing surface cracks in wet areas such as exterior walls and existing roof deck. **WELDCRETE CRACK FILLER** can also be used to repair concrete surface holes.

Application Procedure:

1. Cut all surface cracks using hand cutter, in a U-cut shape and at least 6 mm width and at least 20 mm deep but avoid to hit the steel reinforcement. In repairing concrete surface holes, cut the edges using hand cutter, chisel and removed the loose concrete.
2. Clean the surface using blower or brush, and then dampen the surface. If **WELDCRETE CRACK FILLER** will be used as thin skim coat on top of fresh concrete/mortar surface, make sure to apply it immediately when fresh concrete/mortar is half set to avoid cold joint.
3. Mix 2.4 liter of cement/white cement with 30 grams **WELDCRETE CRACK FILLER** Part A (in a small sachet), mix for at least 30 seconds using cement trowel, then with hand mixer. This mixture can also be used in repairing concrete surface holes up the 3 mm thick.
4. When repairing concrete surface holes more than 3 mm thick, mix 1 kg of cement/white cement, 1.5 kg of clean and sieved sand and with 30 grams **WELDCRETE CRACK FILLER** Part A (in a small sachet), mix for at least 30 seconds using cement trowel, then with hand mixer.
5. Place 1 kg of **WELDCRETE** Crack Filler Part B(liquid) into the mixture and mix again for at least 1.5 minutes using cement trowel, then with hand mixer.
6. Make sure that the crack has no running water leakage during application.
7. Fill the dampened cracks/holes with **WELDCRETE CRACK FILLER** mix using spatula, press the mix towards the full depth of the cut. For horizontal application, re-apply **WELDCRETE CRACK FILLER** mix prior to final setting. For vertical application, re-apply **WELDCRETE CRACK FILLER** mix twice prior to final setting.
8. Upon final setting, apply one layer of **CALCURE B*R** curing compound.

Packaging: 1 kg set

Yield: 0.0012 m³

APPLICATION: CONTACT CEMENTAID FOR SUPPLY AND APPLICATION SERVICE

PT. CEMENTAID SALES AND SERVICES INDONESIA

Jl. Raya Bekasi KM 17 No. 5, Jakarta Timur 13930, Indonesia

Tel. No.: +622146823504 / +622146823505

Website: www.cementaid.co.id / www.cementaid.com

